


# Microsquirt Ignition Coil – IGN4VW



## Notes:

Resistor spark plugs are required to prevent ECU resets.

Disregard numbers on coil pack and refer to above diagram. The coil was originally designed for an inline application with different firing order.

TITLE		REVISIONS	
Microsquirt Ignition Coil IGN-4VW		NO.	DATE DESCRIPTION
DATE ORIGINAL	SCALE		
2/2/2020	NTS		
LATEST REVISION	JOB NO.	CHECKED	DRAWN
Rev. A			MV