PWM Idle Control Solenoid to Relay Board

Bosch Idle Control Solenoid

Outlet to Intake Manifold

Filtered Air Inlet

1
2

FIDLE





Replace Idle Relay with Jumper

12V IGN

OFF
ON / RUN /START
START

Ignition Key

- FACTORY IGNITION - COIL WIRE

BATTERY

Notes:

TITLE: MS2 V3.57 Relay Board PWM Idle Solenoid		REVISIONS			
		NO.	DATE	DESCRIPTION	
			6/20	Add Jumper Diagram	
DATE ORIGINAL: 10/30/2019	SCALE: NTS				
LATEST REVISION: Rev. B	JOB NO.	CHECKED		DRAWN: MV	

THE DUB SHOP